




1277 PE distribution x=5mm y=75mm




Example of a 42PE pulse




Example of a 30PE pulse




Example of a 120PE pulse




Example of a 149PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 107PE pulse




Example of a 97PE pulse




Example of a 65PE pulse




Example of a 59PE pulse




1277 PE distribution x=5mm y=75mm




1277 PE distribution x=5mm y=75mm




1277 PE distribution x=5mm y=75mm




1277 PE distribution x=5mm y=75mm




1277 PE distribution x=5mm y=75mm




Example of a 47PE pulse




Example of a 52PE pulse




Example of a 167PE pulse




Example of a 151PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 63PE pulse




Example of a 67PE pulse




Example of a 79PE pulse




Example of a 70PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 39PE pulse




Example of a 28PE pulse




Example of a 75PE pulse




Example of a 82PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 38PE pulse




Example of a 45PE pulse




Example of a 33PE pulse




Example of a 35PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 40PE pulse




Example of a 58PE pulse




Example of a 81PE pulse




Example of a 86PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 54PE pulse




Example of a 77PE pulse




Example of a 22PE pulse




Example of a 21PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 133PE pulse




Example of a 110PE pulse




Example of a 134PE pulse




Example of a 157PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 34PE pulse




Example of a 24PE pulse




Example of a 27PE pulse




Example of a 32PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 38PE pulse




Example of a 31PE pulse




Example of a 122PE pulse




Example of a 103PE pulse




1277 PE distribution x=5mm y=75mm




Example of a 37PE pulse



Example of a 40PE pulse



Example of a 49PE pulse



Example of a 31PE pulse

