




1271 PE distribution x=50mm y=25mm




Example of a 171PE pulse




Example of a 172PE pulse




Example of a 84PE pulse




Example of a 94PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 112PE pulse




Example of a 128PE pulse




Example of a 75PE pulse




Example of a 117PE pulse




1271 PE distribution x=50mm y=25mm




1271 PE distribution x=50mm y=25mm




1271 PE distribution x=50mm y=25mm




Example of a 29PE pulse




Example of a 20PE pulse




Example of a 28PE pulse




Example of a 22PE pulse




1271 PE distribution x=50mm y=25mm




1271 PE distribution x=50mm y=25mm




Example of a 95PE pulse




Example of a 105PE pulse




Example of a 169PE pulse




Example of a 212PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 233PE pulse




Example of a 294PE pulse




Example of a 74PE pulse




Example of a 87PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 103PE pulse




Example of a 91PE pulse




Example of a 38PE pulse




Example of a 55PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 53PE pulse




Example of a 69PE pulse




Example of a 35PE pulse




Example of a 66PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 61PE pulse




Example of a 62PE pulse




Example of a 59PE pulse




Example of a 42PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 46PE pulse




Example of a 31PE pulse




Example of a 48PE pulse




Example of a 27PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 48PE pulse




Example of a 51PE pulse




Example of a 93PE pulse




Example of a 99PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 79PE pulse




Example of a 37PE pulse




Example of a 36PE pulse




Example of a 20PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 46PE pulse




Example of a 62PE pulse




Example of a 96PE pulse




Example of a 100PE pulse




1271 PE distribution x=50mm y=25mm




Example of a 113PE pulse



Example of a 185PE pulse



Example of a 50PE pulse



Example of a 41PE pulse

