




1163 PE distribution x=1000mm y=75mm




Example of a 149PE pulse




Example of a 118PE pulse




Example of a 108PE pulse




Example of a 109PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 77PE pulse




Example of a 89PE pulse




Example of a 160PE pulse




Example of a 145PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 114PE pulse




Example of a 122PE pulse




Example of a 186PE pulse




Example of a 164PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 88PE pulse




Example of a 80PE pulse




Example of a 118PE pulse




Example of a 85PE pulse




1163 PE distribution x=1000mm y=75mm




1163 PE distribution x=1000mm y=75mm




1163 PE distribution x=1000mm y=75mm




Example of a 107PE pulse




Example of a 118PE pulse




Example of a 42PE pulse




Example of a 44PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 95PE pulse




Example of a 83PE pulse




Example of a 100PE pulse




Example of a 91PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 134PE pulse




Example of a 185PE pulse




Example of a 152PE pulse




Example of a 170PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 161PE pulse




Example of a 155PE pulse




Example of a 159PE pulse




Example of a 150PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 141PE pulse




Example of a 109PE pulse




Example of a 70PE pulse




Example of a 85PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 90PE pulse




Example of a 60PE pulse




Example of a 129PE pulse




Example of a 130PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 112PE pulse




Example of a 138PE pulse




Example of a 154PE pulse




Example of a 168PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 84PE pulse




Example of a 68PE pulse




Example of a 64PE pulse




Example of a 83PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 83PE pulse




Example of a 101PE pulse




Example of a 34PE pulse




Example of a 42PE pulse




1163 PE distribution x=1000mm y=75mm




Example of a 78PE pulse



Example of a 75PE pulse



Example of a 99PE pulse



Example of a 72PE pulse

