




840 PE distribution x=200mm y=75mm




Example of a 47PE pulse




Example of a 57PE pulse




Example of a 36PE pulse




Example of a 33PE pulse




840 PE distribution x=200mm y=75mm




Example of a 47PE pulse




Example of a 40PE pulse




Example of a 39PE pulse




Example of a 45PE pulse




840 PE distribution x=200mm y=75mm




Example of a 51PE pulse




Example of a 42PE pulse




Example of a 49PE pulse




Example of a 58PE pulse




840 PE distribution x=200mm y=75mm




Example of a 80PE pulse




Example of a 56PE pulse




Example of a 66PE pulse




Example of a 66PE pulse




840 PE distribution x=200mm y=75mm




Example of a 88PE pulse




Example of a 103PE pulse




Example of a 65PE pulse




Example of a 71PE pulse




840 PE distribution x=200mm y=75mm




Example of a 68PE pulse




Example of a 67PE pulse




Example of a 83PE pulse




Example of a 97PE pulse




840 PE distribution x=200mm y=75mm




Example of a 91PE pulse




Example of a 86PE pulse




Example of a 74PE pulse




Example of a 79PE pulse




840 PE distribution x=200mm y=75mm




Example of a 104PE pulse



Example of a 122PE pulse



Example of a 132PE pulse



Example of a 120PE pulse

