

🔒 ntuong196 / AED-Tracking Private

Branch: master ▼

AED-Tracking / README.md

Find file

Copy path

 ntuong196 Add API, modify README.md

210b6fa 2 minutes ago

1 contributor

172 lines (109 sloc) 4.68 KB



build failing BrowserStack completed npm package 7.0.1

# QUT AED Tracking

## Discription:

Domain: QUT Heath, Safety and Environment (HES)

Project name: AED Tracking

Goal: Implementing the tracking device and monitoring web app for AED kit of QUT HES.

Project components:

Component	Specification	Cost
Sensor	Raspberry Pi 3 Model B + NEO 6M GPS Module	\$100
API	NodeJS + MongoDB	Free
Web Application	NodeJS + React	Free

## Prerequisite: (For Windows Machine)

This prerequisite similar with MacOS and Linux machine.

1. Install Git bash [here](#)

For version control and SSH to control the Sensor (Raspberry Pi)

2. Install Node and NPM [here](#)

For Web development environment.

## Raspberry Pi:

### Installation:

Initial configuration is based on the guide for unit IFB102 of Prof.Paul Roe.

The document can be found in [Guide Folder](#)

1. Connect to Raspberry Pi by Internal IP Address.

Open Git Bash installed

```
ssh pi@<RASP_PI_IP_ADDRESS>
```

,eg. `ssh pi@192.168.0.18`

This Internal IP Address can be found by terminal command.

```
ifconfig
```

Find IP Address of the `wlan0` interface.

2. Connect to Raspberry Pi using Putty.

Read the instruction in [Guide Folder](#)


3. Connect to Pi Desktop using HDMI or Ethernet cable.

Read the instruction in [here](#)

Open terminal from the Pi

```
sudo apt-get distro-upgrade && sudo apt-get update && sudo apt-get upgrade -y
```

**Wiring Raspberry Pi with the GPS Module:**

**GPS Module**

Wiring table:

NEO-6M GPS	Raspberry Pi	Note
VCC	Pin 1	3.3V

NEO-6M GPS	Raspberry Pi	Note
TX	Pin 10	RX(GPIO15)
RX	Pin 8	TX(GPIO14)
GND	Pin 6	GND

### UART config:

This configuration will allows Raspberry Pi reading the data from GPS module.

Open Terminal from the Raspberry Pi

```
sudo raspi-config
```

Go to Advance option -> turn on serial hardware, turn off serial console

### Install GPS client software:

Open Terminal from the Raspberry Pi

```
sudo apt-get install gpsd-clients gpsd -y
sudo killall gpsd
sudo nano /etc/default/gpsd
```

then add '/dev/serial0' to DEVICE in gpsd file

```
sudo systemctl enable gpsd.socket
sudo systemctl start gpsd.socket
```

Test gps module with command

cgps

Or gpsmon

Remember to terminate those processes to continue the set-up with CTRL + C

## Clone and Run tracking software:

Clone the software


```
git clone https://github.com/ntuong196/aed-tracking`  
cd /aed-tracking/RaspberryPi/py_server`  
python3 gpsdserver.py
```

## NodeJS Server:


On windows (macOs, linux) machine, open terminal (command line)

```
git clone https://github.com/ntuong196/aed-tracking  
cd /aed-tracking/NodeServer  
npm install  
npm start
```

Open Web browser in address localhost:3000/ to view the web page.



Login with default username: `n9776001@qut.edu.au` and password: `toor@101`



## Additional Control the Sensor:

### VNC Server Remote desktop:

```
sudo apt-get remove xrdp vnc4server tightvncserver  
sudo apt-get install xrdp -y
```



then enable VNC interface in raspi-config

Download [VNC Server](#)

Connect to the Raspberry Pi through External IP Address, eg. 192.168.0.18