


# Yaesu VX-8R Quick Reference Guide

## DUPLEX LAYOUT

(Printing on both sides of the same sheet of paper.)

**D** 

**FOLD** **3**

**Yaesu VX-8R Quick Reference**

**Changing Bands**  
 SC-M BND DN BAND BAND UP  
 SC-M BND DN BAND BAND DOWN

**VFO Tuning**  
 DIAL OR DIAL 1 MHz STEPS  
 FREQUENCY UP OR DOWN OPTIONS

**VFO Scan**  
 DW MT SC-M BND DN V/M BAND + DIAL  
 SET VFO HOLD SET BW DIAL REVERSE DIRECTION START/STOP HOLD 1 SEC  
 OPTIONS

**Squelch**  
 FW MONI/T-CALL DIAL PTT  
 ADJUST CONFIRM

**Tx Power**  
 FW TX PO  
 CYCLE PO

**FM/AM Tuning**  
 A FW RADIO 0 DIAL  
 SELECT VFO A TUNE

**FOLD** **3**

**Yaesu VX-8R Quick Reference**

**Wx Band**  
 A FW 9 WX YZ BAND DIAL  
 CYCLE TO WX TUNE WX

**AF Dual Monitoring**  
 A B AF-DUAL 7 PQ RS MONI/T-CALL + DIAL  
 SET BANDS TOGGLE DUAL TUNE A/B

**Store VFO in Memory**  
 FW DIAL FW  
 1/2 SEC SELECT LOCATION STORE

**Memory Recall**  
 DW MT V/M DIAL DW MT V/M  
 MEMORY SELECT LOCATION RETURN TO VFO

**Mute**  
 MENU DIAL MENU DIAL PTT  
 1 SEC #62 ENABLE SET LEVEL CONFIRM

**FOLD** **3**

**Yaesu VX-8R Quick Reference**




**Memory Scanning**  
 DW MT SC-M BND DN PTT  
 V/M BAND + DIAL  
 MEMORY HOLD SET MODE CANCEL

**Dual Watch/Priority Scan**  
 DW MT SC-M BND DN DW MT  
 V/M FW DIAL BAND DIAL V/M  
 MEMORY 1 SEC CHANNEL PRIORITY CHANNEL 1 SEC

**Smart Search**  
 MENU DIAL MENU PTT  
 1 SEC #88 MODE CONFIRM SPS SQ TYP MODE + DIAL  
 HOLD SEARCH

**CTSS Setup**  
 FW SPS SQ TYP MODE DIAL SELECT "TONE" OR "TONE SQL" SPS SQ TYP MODE  
 SELECT SQL SAVE

**CTSS Operation**  
 MENU DIAL MENU DIAL MENU  
 1 SEC #99 ADJUST TONE CONFIRM

**A**  **B**  **C** 

## INSTRUCTIONS

- 1 PRINT BOTH SIDES
- 2 TRIM (A, B, C & D)
- 3 FOLD


**VX8R@GEARMONKIES.COM**  
 PLEASE SEND ALL COMMENTS AND/OR CORRECTIONS  
 TO THE ABOVE EMAIL ADDRESS. THANK YOU.  
 VERSION .5b

# SIDE A

# Yaesu VX-8R Quick Reference Guide


## DUPLEX LAYOUT


(Printing on both sides of the same sheet of paper.)

**D** 

**FOLD** **3**


**FOLD** **3**

**A** 

**B** 

**FOLD** **3**

**FOLD** **3**

**C** 

**Yaesu VX-8R Quick Reference**

**Channel Frequencies**

SC-M BND ON BAND DIAL DIAL

BAND	VFO-A	VFO-B
1 SW Band	1.8-30 MHz	-
2 50 MHz Band	30-76 MHz	30-76 MHz
3 AIR Band	108-137 MHz	108-137 MHz
4 VHF HAM Band	137-174 MHz	137-174 MHz
5 VHF TV Band	174-222 MHz	174-222 MHz
6 INFO 1 Band	222-420 MHz	222-420 MHz
7 UHF HAM Band	420-470 MHz	420-470 MHz
8 UHF TV Band	470-774 MHz	470-580 MHz
9 INFO 2 Band	774-999.99 MHz	-

**Sub Mode Menus**

MENU DIAL MENU DIAL PTT

1 SEC SELECT ADJUST SET MODE CONFIRM

**Menu Maintained By**

**VX8R@GEARMONKIES.COM**

PLEASE SEND ALL COMMENTS AND/OR CORRECTIONS TO THE ABOVE EMAIL ADDRESS. THANK YOU.

VERSION .5b

**Yaesu VX-8R Quick Reference**

**Menu Menus**

1. Antenna AM	29. DTMF Manual/auto
2. Antenna FM	30. DTMF Select
3. Antenna Att	31. DTMF Speed
4. APO	32. EAI
5. ARTS Beep	33. EAI Time
6. Arts Interval	34. Emergency Select
7. Bank Link	35. Extended Menu
8. Bank Name	36. FW Key Hold Time
9. BCLO	37. Half Deviation
10. Beep Edge	38. Home VFO
11. Beep Level	39. Home/reverse
12. Beep Melody	40. Int Manual/auto
13. Beep Select	41. Internet
14. Bell Ringer	42. Internet Code
15. Bell Select	43. Internet Key
16. Bluetooth P-code	44. Internet Mode
17. Bluetooth Set	45. Internet Select
18. Busy LED	46. Lamp
19. Ch Counter	47. Language
20. Clock Shift	48. LCD Contrast
21. CW ID	49. LCD Dimmer
22. CW Learning	50. LED Light
23. CW Pitch	51. Lock
24. CW Training	52. Memory Fast Step
25. DC Voltage	53. Memory Name
26. DCS Code	54. Memory Protect
27. DCS Inversion	55. Memory Skip
28. DTMF Delay	56. Memory Write

**Yaesu VX-8R Quick Reference**

**Menu Menus (Continued)**

57. Message List	85. Sensor Information
58. Message Register	86. Set Mode Csr
59. Message Select	87. Set Mode Format
60. Mic Gain	88. Smart Search
61. Moni/t-call	89. S-meter Symbol
62. Mute	90. Speaker Out
63. Off Timer	91. Spec-analyzer
64. On Timer	92. Sql Level
65. Opening Message	93. Sql S-meter
66. Pager Ans-back	94. Sql Split
67. Pager Code-RX	95. Sql Type
68. Pager Code-TX	96. Step Frequency
69. Password	97. Stereo
70. Pr Frequency	98. Time Set
71. Pri Revert	99. Tone Frequency
72. Pri Time	100. Tone-srch Mute
73. PTT Delay	101. Tone-srch Speed
74. Rpt ARS	102. Tot
75. Rpt Shift	103. Unit Offset
76. Rpt Shift Freq	104. Unit Select
77. RX AF Dual	105. VFO Mode
78. Rx Mode	106. VFO Skip
79. Save RX	107. Volume Mode
80. Save TX	108. VOX
81. Scan Lamp	109. VOX Delay
82. Scan Re-start	110. Wave Monitor
83. Scan Resume	111. Wx Alert
84. Sensor Display	

## INSTRUCTIONS

- 1 PRINT BOTH SIDES
- 2 TRIM (A, B, C & D)
- 3 FOLD

**VX8R@GEARMONKIES.COM**  
PLEASE SEND ALL COMMENTS AND/OR CORRECTIONS  
TO THE ABOVE EMAIL ADDRESS. THANK YOU.  
VERSION .5b

# SIDE A