





To zero calibrate the probe, disconnect all cables, touch the pads at the back of the board with a +9V battery and press the button for 10 secs.



BLE STEPPER MOTOR MONITOR v1.3



TODD: Consider replacing the DC/DC with an insulated one.