


owlDrive and Husqvarna cutter motor wiring and settings
7.2.2024



```
owlDrive main menu (firmware ver 36, database ver 28. CanNode 3 broadcast 63)
0. Exit menu
1. Selected profile (preset): Default (motor=Generic 1-phase-BLDC (1-channel encoder) pcb=owlRobotics_black_edition_Board)
2. Selected motor (preset): Generic 1-phase-BLDC (1-channel encoder)
3. Selected PCB: owlRobotics_black_edition_Board
4. Profile menu (align=0 invertDir=0 enableIn=0 pwmIn=0 fanDuty=0.50 serialMonOut=1 endSwIn=0 endSwActLow=1 endSwPosDirTg=
5. PCB menu (shuntR=7.41 opAmpGain=-1.00 opAmpOfs=1.65 overCurr=0.08A overVolt=1 underVolt=12.00 emfProtect=0 temp=1)
6. Motor menu (typ=BLDC-1-phase Usup=24V sen=Enc(1ch) kv=183 rpm=4400 R=0.9000 ohm L=0.00070 H pp=0 alignV=0.00 zeroOfs=0
7. Motion Control mode menu (torque torqueCtl=voltage usePhR=0 useKV=0 usePhL=1 limits U=+-15.00 I=+-2.00)
8. FOC Modulation type: SinePWM
9. Phase tester
10. CAN menu (canSpeed=1000kbps canMsgId=300 canNodeId=1 canNodeIdBroadcast=63 broadcastMask=0 followId=0 followVal=1)
11. Save to EEPROM and exit (required to make changes persistent)
12. Save to EEPROM and reboot (required if changed motor/pcb/sensor)
```

To test motor send: M5, M12 etc. (with the desired output phase voltage/torque)

/dev/ttyACM0													
M5													
canNode 2	sec 31	lps 25288	focps 5470	tg(torque->voltage) 0.00	v 0.0(0rpm)	Usup 26.58	BEMF						
Target: 0.000													
canNode 2	sec 32	lps 25269	focps 10765	tg(torque->voltage) 0.00	v 0.0(0rpm)	Usup 26.83	BEMF						
canNode 2	sec 33	lps 25280	focps 5468	tg(torque->voltage) 0.00	v 0.0(0rpm)	Usup 26.77	BEMF						
Target: 5.000													
canNode 2	sec 34	lps 24852	focps 13950	tg(torque->voltage) 5.00	v 178.2(1702rpm)	Usup 26.83							
canNode 2	sec 35	lps 24705	focps 5431	tg(torque->voltage) 5.00	v 200.4(1913rpm)	Usup 26.47							
canNode 2	sec 36	lps 24683	focps 5425	tg(torque->voltage) 5.00	v 200.4(1913rpm)	Usup 26.50							

Sunray settings:

```
#define MOW_MOTOR_COUNT 1
#define MOW_ADJUST_HEIGHT false
#define MOW_OVERLOAD_CURRENT 0.08
#define ENABLE_OVERLOAD_DETECTION true
#define ENABLE_FAULT_DETECTION true
#define ENABLE_RPM_FAULT_DETECTION true
```