


PRIMARY SIDE



ASSEMBLY NOTES:

1. Insert 0-Ohm 0603 resistor in following jumper locations:

JP1 : POS 1-2

JP2 : POS 2-3


JP3 : POS 2-3

JP4 : POS 2-3

JP5 : POS 1-2

2. Insert link (M000389) on P10.

3. Attach Stick-on-feet (M022278) at 4 corners on secondary side.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MM TOLERANCES DECIMALS FRACTIONS ANGLES .XX ±0.25 ± 1/32 ±.2 XXX ±0.127	ASSEMBLY		 ANALOG DEVICES		ANALOG DEVICES INTERNATIONAL ERDC Building Raheen Business Park Raheen, LIMERICK, IRELAND		
	APPROVAL	DATE					TITLE
MATERIAL	DRAWN BY Pat Sheahan	01NOV2019	EVAL-CN0540-ARDZ				
	DESIGNED						
	CHECKED						
FINISH	APPROVED		SIZE	FSCM NO	DRAWING NUMBER	REV	
	MFG ENGINEER		A4		01-059358	B	
DO NOT SCALE DWG			SCALE	1/1		SHEET 1 OF 2	

