

The pads and traces in red represent the RF net.
They should be matched to 50 ohm impedance.

