


CHEMICAL PREPARATION

LIME PREPARATION

Auto-Preparation (Controlled by Level Sensor)




To Avoid Chemical hardened in tank

During Auto-Preparation


1H ChangeOver interval between pump

Start Circulation Pump P203A/B


To Avoid Chemical hardened in Dosing Line



Tank Switch-Over



**SODIUM/CAUSTIC/ALUM
PREPARATION**




SBR DOSING


ALUM DOSING

During AERATION
PROCESS


LIME DOSING




TERTIARY DOSING POINT



Chlorinization Tank DOSING



EFFLUENT Disinfection TANK DOSING



TERTIARY TREATMENT PLANT

