


Keyboard Layouts 500 Duo


The diagram illustrates the Keyboard Layouts 500 Duo PCB, showing various button layouts and pin connections. The PCB is a grey rectangular board with two blue button housings. The left housing has a red button, and the right housing has a red button. The right housing also features a 5-pin header with pins labeled 1 through 5. A legend on the right side of the image defines the pin numbers: 1 Left, 2 Right, 3 Up, 4 Down, and 5 Common (GND). The diagram shows several button layouts with numbers 1 through 8, and letters A, B, X, and Y. The top right corner shows a detailed view of the button layout with pins P1, C1, and P2. The bottom left corner shows a small inset image of the physical PCB.

Legend:


- ① Left
- ② Right
- ③ Up
- ④ Down
- ⑤ Common (GND)




Keyboard Layouts All





DragonRise Inc. Generic USB Joystick



MAME




Generic



Keyboard Layouts Pandora

Signal definitions for Jamma Port

PS3	PC	pandora game	2P	1P	pandora game	PC	PS3
+5V	+5V	+5V	1	1	+5V	+5V	+5V
SELECT	J	NC	2	2	NC	J	SELECT
	I	NC	3	3	NC	I	
R2	H	NC	4	4	NC	H	R2
R1	G	NC	5	5	NC	G	R1
L2	F	2P-F	6	6	1P-F	F	L2
L1	E	2P-E	7	7	1P-E	E	L1
	D	2P-D	8	8	1P-D	D	
	C	2P-C	9	9	1P-C	C	
	B	2P-B	10	10	1P-B	B	
	A	2P-A	11	11	1P-A	A	
RIGHT	RIGHT	2P-RIGHT	12	12	1P-RIGHT	RIGHT	RIGHT
LEFT	LEFT	2P-LEFT	13	13	1P-LEFT	LEFT	LEFT
DOWN	DOWN	2P-DOWN	14	14	1P-DOWN	DOWN	DOWN
UP	UP	2P-UP	15	15	1P-UP	UP	UP
START	START	2P-START	16	16	1P-START	START	START
NC	NC	PAUSE	17	17	PAUSE	NC	NC
GND	GND	GND	18	18	GND	GND	GND
The handle switch			19	19	The handle switch		
	NC	NC	20	20	NC	NC	



APPENDIX