


PACKAGING and COMPONENTS:



OVERVIEW: This towel bar has built-in adjustment available if the holes do not line up to the center. Each towel bar end has a rotatable barrel with an offset hole that allows the adjustment. See the Figures on the back page for the installation conditions.

STEP 1: Determine which Figure and parts should be used.

- Choose one of the Figures on the back page based on the hole distances. Measure the center to center distance between the holes on the outside panel.
- Measure the center to center distance between the center holes in the towel bar.
- If the measurements are the same use Fig.#1 --> Parts:7 & 12 in Package B and parts 2 & 3 (use center hole) and 5 & 11 in Package C.
- If the two measurements differ by up to 5/16" +/- , use Fig.#2 --> Parts 8 & 12 in Package B and parts 2 & 3 (use center hole), and 5 & 11 in Package C.
- If the two measurements differ by up to 9/16" +/- , use Fig.#3 --> Parts 8 & 12 in Package B and Parts 2 & 3 (outside hole), and 6 & 10 in Package C.

STEP 2: Position the panel, install the hole plugs.

- Slide the glass panels to their proper closed position.
- Notice that the two center holes are inaccessible because of the overlap in the panels. Make them accessible by sliding each panel to the opposite wall.
- Install the Male and Female Clear Plastic Hole Plug (#13), into the exposed hole on the inside panel.

STEP 3: Towel Bar.

- BEFORE applying the towel bar to the glass, adjust the rotating inserts to fit the holes in the glass using the appropriate Figure on the back page . Make sure that the inserts are not exposed outside of the towel bar ends.
- Insert the appropriate back plate per the Figure you selected into the exposed hole on the outside panel and thread it into either the center or the offset hole in the towel bar depending on the figure used. While supporting the loose end of the towel bar, attach the knob assemblies as shown to secure the towel bar.


STEP 4: Inside Pull Assembly.

- Install the back to back knob assembly on the inside panel. Installation of this assembly is the same for all three figures.




WARNING: This shower door should not be installed without the supplied Step Washers and Back up Plate. These parts incorporate a plastic "grommet" that protects the inside of the glass holes from touching the mounting screws. If the screws touch the glass, the glass can break and create a serious safety hazard. Do not attempt to adjust the rotating inserts in the towel bar while the towel bar is attached to the glass. This can cause the glass to break and create a serious safety hazard.

(FIG.#1)
NORMAL INSTALLATION
 (No Adjustment needed)



(FIG.#2)
INSTALLATION FOR UP TO 5/16" ADJUSTMENT



(FIG.#3)
INSTALLATION FOR UP TO 9/16" ADJUSTMENT

