




This layout can be used if the board-mounted RJ45 is not used and board J1 not used.
 Jumper pins 1 and 2 of main board J1.
 If you wish to use a battery on the HUZZAH32 you will need to connect up board J1 and J2.



This layout is used if you use the board-mounted RJ45 connector. Supply voltage from USB should have a diode inline or you risk back-feeding 5V when 12V is supplied.



Sheet: /
 File: turning-feather-external.sch

Title:

Size: User Date:
 KiCad E.D.A. eeschema (5.1.4-0-10_14)

Rev:
 Id: 1/1