

HS2P_voidSend16BitSynchronous

HS2P_voidSend8BitSynchronous

TIM1_voidSetBusyWait

```
graph LR; A[HS2P_voidSend16BitSynchronous] --> C[TIM1_voidSetBusyWait]; B[HS2P_voidSend8BitSynchronous] --> C;
```

The diagram illustrates a functional dependency or call sequence. Two functions, 'HS2P_voidSend16BitSynchronous' and 'HS2P_voidSend8BitSynchronous', are shown on the left. Both have arrows pointing to a single function, 'TIM1_voidSetBusyWait', which is highlighted with a gray background. This suggests that both send functions eventually call the 'TIM1_voidSetBusyWait' function to manage the timer's busy state.