

Operator Panel

Motor On / Off



On



Off



Note: The Three-position enabling device is inactive

Operator Mode



ROB_R



Vaccu...



wobj0



ROB_L



Camera
wobj0

100 %



Hide Details >>



Increments



None



Small



Medium



Large



User

<< Show Values



Tasks to Stop and Start

Tasks	Status
<input checked="" type="checkbox"/> T_ROB_L	Normal
<input checked="" type="checkbox"/> T_ROB_R	Normal

