

DATA

EDIT

DISPLAY

UTILITY



JOB



GENERAL



VARIABLE

B001

IN/OUT



ROBOT



SYSTEM INFO



TOOL COORDINATE

CURRENT
POSITIONPOWER ON/OFF
POSMANIPULATOR
TYPECOMMAND
POSITION

TOOL



ANALOG MONITOR



SERVO MONITOR



INTERFERENCE

OVERRUN
& S-SENSOR

WORK HOME POS

SHOCK SENS
LEVEL

LIMIT RELEASE



SECOND HOME POS



USER COORDINATE



ARM CONTROL



DROP AMOUNT



HOME POSITION



SHIFT VALUE

Main Menu

Step In Menu

I/F Panel

EASY