

Also contains rca input for video/audio

T501 transformer

Front panel PCB:
(channel switches+tuner pots+msx reset/load/run buttons)

Tube neck PCB


4CEC PCB

4CEB PCB

4CEE PCB

4CED PCB

Sheet: /
File: paxxon_pct_55.sch
Title:
Size: A2 Date:
KiCad E.D.A. kicad (5.1.5)-3 Rev:
Id: 1/1



Also contains rca input for video/audio

T501 transformer

Front panel PCB:
(channel switches+tuner pots+msx reset/load/run buttons)

Tube neck PCB

4CEC PCB

4CEB PCB

4CEE PCB

4CED PCB

Sheet: /
File: paxxon_pct_55.sch
Title:
Size: A2 Date:
KiCad E.D.A. kicad (5.1.5)-3 Rev:
Id: 1/1

