



# INSTALLATION INSTRUCTIONS FOR ATLASGS60HRS

**WARNING:** Read the following carefully before attempting to install or service this unit! Failure to do so may result in bodily injury, property and/or fixture damage. Retain this sheet for future reference.

## GENERAL DESCRIPTION

This luminaire is designed for indoor and outdoor ceiling mounted application areas and is suitable for use in wet locations. It should not be installed in locations with limited ventilation or within enclosures with high ambient temperatures.

## CAUTION:

Please be sure to follow local electrical codes. Luminaires should only be installed by a qualified electrician.

## WIRING NOTE:

Some ATLAS models may have different wiring coming from the driver. Please refer to the color code chart below:


HOT = Brown or Black

NEUTRAL = Blue or White

GROUND = Green or green/yellow

## ELECTRICAL CONNECTIONS

Luminaires are factory wired for specific voltages. Make sure the supply voltage is compatible with the luminaire. Universal voltage luminaires may be used with any voltage between 120V and 277V.



## Mounting Instructions

1. Cut 12" x 12" hole in ceiling.
2. Using the square mounting plate as a template, drill 4 holes.
3. Sandwich the ceiling between the square mounting plate and the Atlas.
4. Secure the luminaire with the supplied hardware.