



HEADLAMP WASHER

HEADLAMP WASHER

Wiring Diagram —HLC—

To ESM
WW-HLC-01



REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M48, M49, M50) -ELECTRICAL UNITS

HEADLAMP WASHER

WW-HLC-02

