


TROUBLE DIAGNOSIS





Wiring Diagram — SRS—

SRS-SRS-01



TROUBLE DIAGNOSIS

SRS-SRS-02



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)

MHWA0039E

TROUBLE DIAGNOSIS

SRS-SRS-03



MHWA0040E