


Race Studio 3


Odometers management with RS3

Question:

How can I manage the system odometers using RS3?

Answer:

- Run RS3
- connect your device to a PC
- enter "Configurations"  page and click the name of your device in "Connected Devices" section
- the related page shows up: by default it shows "Live Measures" layer
- click "Odometers": a table appears: it shows a System odometer and four User odometers



MXL2 ID 4301285


Live Measures Download WiFi and Properties Settings Tracks **Odometers** Logo Firmware

Receive

<input checked="" type="checkbox"/>	Name	Timer (hh:mm)	Distance (km)	reset
<input checked="" type="checkbox"/>	System	22:11	2090	
<input checked="" type="checkbox"/>	Usr 1	04:58	828	reset
<input checked="" type="checkbox"/>	Usr 2	04:38	755	reset
<input checked="" type="checkbox"/>	Usr 3	04:45	780	reset
<input checked="" type="checkbox"/>	Usr 4	04:51	801	reset



Race Studio 3



Odometers work this way:

- "System": cannot be disabled nor reset or renamed; you can modify measure unit (miles or metres) and decimal places clicking on the setting icon on the right of "Distance" column;
- "User": can be disabled; you can modify measure unit (miles or meters) and decimal places clicking on the setting icon on the right of "Distance" column; user odometer can be renamed

In the following table user odometers name and decimal places have been modified.

