


2020 > Engine > D 2.0 TCI-R(Enhanced Euro-6) > Schematic Diagrams > Power & Ground > Fuse & Relay Information > Schematic Diagrams

Fuse & Relay Information (8)


SD100-8

SUB Junction Block

D4HA/D4HB : R2.0L/2.2L



Relay Type

Relay NO.	Symbol	Circuit Protected	Relay Type
E37	¹ PTC HEATER	RLY. 1 (PTC Heater Relay #1)	MICRO PLUG
E38	² PTC HEATER	RLY. 2 (PTC Heater Relay #2)	MICRO PLUG
E39	³ PTC HEATER	RLY. 3 (PTC Heater Relay #3)	MICRO PLUG
E40		RLY. 4 (Fuel Filter Heater Relay)	MICRO PLUG

※ USE THE DESIGNATED FUSE AND RELAY ONLY