



=====

[Errno 98] Address already in use

=====

Error occurred in line number 205

```
=====
##### SYSTEM LOGS #####
=====
```

```
Oct 29 23:14:16 mcb1 daemon.info netopeer2-server[980]: Trying to connect via IPv4 to 192.168.170.85:4334.
Oct 29 23:14:16 mcb1 daemon.info netopeer2-server[980]: getsockopt() error (Connection refused).
Oct 29 23:14:17 mcb1 daemon.info netopeer2-server[980]: Trying to connect via IPv4 to 192.168.170.85:4334.
Oct 29 23:14:17 mcb1 daemon.info netopeer2-server[980]: getsockopt() error (Connection refused).
Oct 29 23:14:17 mcb1 auth.info sshd[9424]: Accepted password for installer from 192.168.170.85 port 59148 ssh2
Oct 29 23:14:17 mcb1 authpriv.info sshd[9424]: pam_unix(sshd:session): session opened for user installer by (uid=0)
```

Expected Result : The NETCONF server replies rejecting the protocol operation with an "access-denied" error.

=====

***** **Actual Result** *****

=====

=====

***** **FAIL_REASON** *****

=====

[Errno 98] Address already in use

=====

Access Control NMS (negative case) = FAIL

=====