



=====

[Errno 98] Address already in use

=====

Error occurred in line number 144

```
=====
##### SYSTEM LOGS #####
=====
```

```
Oct 29 23:11:13 mcb1 daemon.info netopeer2-server[980]: Trying to connect via IPv4 to 192.168.22.79:4334.
Oct 29 23:11:13 mcb1 daemon.info netopeer2-server[980]: getsockopt() error (Connection refused).
Oct 29 23:11:14 mcb1 daemon.info netopeer2-server[980]: Trying to connect via IPv4 to 192.168.22.79:4334.
Oct 29 23:11:14 mcb1 daemon.info netopeer2-server[980]: getsockopt() error (Connection refused).
Oct 29 23:11:14 mcb1 auth.info sshd[7886]: Accepted password for operator from 192.168.22.79 port 44430 ssh2
Oct 29 23:11:14 mcb1 authpriv.info sshd[7886]: pam_unix(sshd:session): session opened for user operator by (uid=0)
```

Expected Result : The O-RU NETCONF server replies by silently omitting data nodes and their descendants to which the client does not have read access from the <rpc-reply> message

=====
***** **Actual Result** *****
=====

=====
***** **FAIL_REASON** *****
=====

[Errno 98] Address already in use
=====

=====
Access Control Sudo (negative case) = FAIL
=====