


Position of Parts in Body (RHD 4-Door Pick-Up)



Position of Parts in Body (RHD 4-Door Pick-Up)

T8	Fuel Pump (Sub)
T9	Fuel Sender Gage Assembly (Rear)
T10	Trailer Socket
T11	Back Buzzer Assembly
T12	License Plate Light Assembly RH
T13	License Plate Light Assembly RH
T14	Rear Combination Light Assembly RH
T15	License Plate Light Assembly LH
T16	License Plate Light Assembly LH
T17	Rear Combination Light Assembly LH
T18	Rear Fog Light Socket & Wire
T19	Fuel Sender Gage Assembly (Rear)
U1	Front Door Courtesy Light Switch Assembly LH
U2	Rear Door Courtesy Light Switch Assembly LH
V1	Rear Differential Lock Position Switch
V2	Differential Lock Shift Actuator
V3	Rear Speed Sensor (Skid Control Sensor Wire)
Y5	No. 1 Room Light Assembly
i1	Outer Rear View Mirror Assembly LH
j1	Outer Rear View Mirror Assembly RH

Position of Parts in Body (RHD 4-Door Pick-Up)

