



Position of Parts in Instrument Panel (LHD)




Position of Parts in Instrument Panel (LHD)

I5	Front Blower Motor (Heater Blower Case)
I7	Blower Resistor
I8	No. 2 Four Wheel Drive Control ECU
I9	Deceleration Sensor
I11	Cooler Stabilizer Amplifier Assembly
I12	Cooler Stabilizer Amplifier Assembly
I13	No. 1 Heater Control Indicator Light Assembly
I14	Rear Heater Blower Switch
I15	Heater Blower Switch Assembly
I16	No. 1 Cooler Thermistor
I17	DLC3
I19	Stop Light Switch Assembly
I20	Diode (Door Courtesy)
I21	Diode (Interior Light)
I24	Diode (Transfer L4 Position Switch)
I26	Wiper Lock Switch (Limit Switch Assembly)
I28	Turn Signal Flasher Assembly
I42	Preheating Timer Assembly
I43	Accelerator Pedal Sensor Assembly
I45	Diode (Sub Tank Relay)
I49	Motor Antenna Control Relay
I50	Clutch Switch Assembly
I51	Airbag Sensor Assembly
I54	No. 5 Junction Connector
I56	No. 7 Junction Connector
I67	No. 16 Junction Connector
I68	No. 17 Junction Connector
I69	No. 18 Junction Connector
I70	No. 19 Junction Connector
I71	No. 20 Junction Connector
I72	No. 21 Junction Connector
I73	No. 22 Junction Connector
I75	No. 17 Junction Connector
I77	No. 1 CAN Junction Connector
I78	No. 1 CAN Junction Connector
I79	No. 1 CAN Junction Connector
I80	No. 2 CAN Junction Connector
I82	No. 2 CAN Junction Connector
I87	Front Blower Motor (Heater Blower Case)
I88	Cooler Stabilizer Amplifier Assembly
I92	Preheating Timer Assembly
I93	No. 5 Junction Connector
I94	No. 7 Junction Connector
I95	No. 18 Junction Connector
I96	No. 20 Junction Connector
I97	No. 32 Junction Connector
I98	No. 17 Junction Connector
I99	No. 17 Junction Connector
I100	No. 1 CAN Junction Connector
I101	No. 2 CAN Junction Connector
I117	No. 35 Junction Connector
I118	No. 36 Junction Connector
I119	No. 6 CAN Junction Connector
I120	No. 6 CAN Junction Connector
I121	No. 6 CAN Junction Connector
I122	No. 6 CAN Junction Connector
I123	No. 6 CAN Junction Connector
I124	No. 6 CAN Junction Connector


Position of Parts in Instrument Panel (LHD)




90980-12488




90980-11136




90980-10848




90980-10845



90980-11971




90980-12477




90980-11159




90980-10794




90980-10876



90980-11918




90980-11665




90980-11118

(Before Aug. 2016 Production 1GR-FE, From Aug. 2016 Production 1GR-FE w)




90980-11118


(o ABS, Before Aug. 2016 Production 1VD-FTV)



90980-10962




90980-10962




90980-11608



90980-10870




90980-12475




90980-12477


Position of Parts in Instrument Panel (LHD)




90980-12303




90980-10962




90980-10819




90980-10906




90980-12710




90980-12479




90980-12479




90980-11915




90980-12478



90980-12479




90980-11915



90980-12479

Position of Parts in Instrument Panel (LHD)



Position of Parts in Instrument Panel (LHD)

