

Single button actions		
<b>1</b> Play "key1.mp3" [3001]	<b>2</b> Music Player : Previous song [3002]	<b>3</b> Play "key3.mp3" [3003]
<b>4</b> Play "key4.mp3" [3004]	<b>5</b> Music Player : Play/Stop [3005]	<b>6</b> Play "key6.mp3" [3006]
<b>7</b> Play "key7.mp3" [3007]	<b>8</b> Music Player : Next song [3008]	<b>9</b> Play "key9.mp3" [3009]
<b>★</b> Start command sequence	<b>0</b> Time Travel	<b>#</b> Abort command
	<b>↑</b> Volume +	
<b>←</b> Chase speed -	<b>OK</b> Execute command	<b>→</b> Chase speed +
	<b>↓</b> Volume -	

# Flux Capacitor

DR. E. BROWN ENTERPRISES  
24 HR. SCIENTIFIC SERVICES



Special key sequences	IR	TCD/HA
Select chase sequence style (0 - 9)	*1x↵	301x
Disable <b>flux sound</b>	*20↵	3020
Enable <b>flux sound</b>	*21↵	3021
Enable <b>flux sound</b> (30 seconds)	*22↵	3022
Enable <b>flux sound</b> (60 seconds)	*23↵	3023
Set relative flux volume level (0 - 3)	*3x↵	303x
Select volume level (00 - 19)	*3xx↵	33xx
Enable volume knob	*399↵	3399
Set <b>minimum box light level</b> (0 - 4)	*40x↵	340x
<b>Music Player</b> : Set folder number	*5x↵	305x
<b>Music Player</b> : Shuffle off	*222↵	3222
<b>Music Player</b> : Shuffle on	*555↵	3555
<b>Music Player</b> : Go to song 000	*888↵	3888
<b>Music Player</b> : Go to song xxx	*888xxx↵	3888xxx
Play "keyX.mp3" (X = 1 - 9)	*50x↵	350x
Toggle <b>IR remote command lock</b>	*70↵	3070
<b>Re-activate</b> or <b>connect</b> WiFi	*77↵	-
Reset chase speed	*80↵	3080
Toggle usage of Speed knob	*81↵	3081
Say current IP address	*90↵	3090
Enter TCD remote control mode*	*95↵	3095
Quit TCD remote control mode*	-	3097
Restart the Flux Capacitor	*64738↵	3064738
Delete static IP address	*123456↵	3123456
Forget learned IR rem. control	*654321↵	3654321

Control of FC through TCD requires BTTFN connection.

\* Remote controlling the TCD keypad requires BTTFN connection.  
Keys 0-9 and OK are sent as brief presses; \*x sends key x as "held".  
# quits remote control mode.