

Single button actions		
1 Play "key1.mp3" [3001]	2 Music Player : Previous song [3002]	3 Play "key3.mp3" [3003]
4 Play "key4.mp3" [3004]	5 Music Player : Play/Stop [3005]	6 Play "key6.mp3" [3006]
7 Play "key7.mp3" [3007]	8 Music Player : Next song [3008]	9 Play "key9.mp3" [3009]
★ Start command sequence	0 Time Travel	# Abort command
	↑ Volume +	
← Chase speed -	OK Execute command	→ Chase speed +
	↓ Volume -	

Flux Capacitor

DR. E. BROWN ENTERPRISES
24 HR. SCIENTIFIC SERVICES



Special key sequences	IR	TCD/HA
Select chase sequence style (0 - 9)	*1x↵	301x
Disable flux sound	*20↵	3020
Enable flux sound	*21↵	3021
Enable flux sound (30 seconds)	*22↵	3022
Enable flux sound (60 seconds)	*23↵	3023
Set relative flux volume level (0 - 3)	*3x↵	303x
Select volume level (00 - 19)	*3xx↵	33xx
Enable volume knob	*399↵	3399
Set minimum box light level (0 - 4)	*40x↵	340x
Music Player : Set folder number	*5x↵	305x
Music Player : Shuffle off	*222↵	3222
Music Player : Shuffle on	*555↵	3555
Music Player : Go to song 000	*888↵	3888
Music Player : Go to song xxx	*888xxx↵	3888xxx
Play "keyX.mp3" (X = 1 - 9)	*50x↵	350x
Toggle IR remote command lock	*70↵	3070
Re-activate or connect WiFi	*77↵	-
Reset chase speed	*80↵	3080
Toggle usage of Speed knob	*81↵	3081
Say current IP address	*90↵	3090
Enter TCD remote control mode*	*95↵	3095
Quit TCD remote control mode*	-	3097
Restart the Flux Capacitor**	*64738↵	3064738
Delete static IP address**	*123456↵	3123456
Forget learned IR rem. control**	*654321↵	3654321

Control of FC through TCD requires BTTFN connection.

* Remote controlling the TCD keypad requires BTTFN connection.
Keys 0-9 and OK are sent as brief presses; *x sends key x as "held".
quits remote control mode. ** Not through HA/MQTT