

OSCILLATOR BANK

1

OSC 1 TYPE

2

OSC 1 PITCH

3

WAVE FORM

4

MOD AMT

5

OSC 2 MOD

6

OSC 2 PITCH

7

OUTPUT MODE

8

MOD AMT

MIXER

9

OSC 1 LEVEL

10

OSC 2 LEVEL

11

MOD 1 AMT

12

MOD 2 AMT

VARIABLE FILTER BANK

13

HPF CUTOFF

14

RESONANCE

15

MOD 1 AMT

16

MOD 2 AMT

17

LPF CUTOFF

18

RESONANCE

19

MOD 1 AMT

20

MOD 2 AMT

AMPLITUDE CORTEX

21

WAVE FORM

22

FREQUENCY

23

DELAY

24

ATTACK

25

RELEASE

26

TEMPO

27

ATTACK

28

DECAY

29

SUSTAIN

30

RELEASE

CLOCK

31

STEPS

32

MELODY

33

EVOLVE

34

MEMORY

35

DRUMS

36

VOLUME

37

ALL OSC LPF HPF MOD 1 IN

38

ALL OSC MOD 2 IN

38

MIXER OSC1 IN

39

LPF MOD 2 IN

40

HPF MOD 2 IN

41

VCA CTRL IN

42

OSC1 OUT

43

OSC2 OUT

44

OUT

45

OUT

46

OUT

47

REV OUT

48

DRUMS IN

49

OSC1 MOD IN

50

CLOCK

51

REV OUT

52

CTRL IN

53

EG1 TRIG IN

54

OSC2 PITCH IN

55

FX MOD IN

56

OSC2 MOD IN

57

IN

58

OUT

59

IN

60

OUT

61

OUT

62

DRIFT OUT

63

DRUMS OUT

64

RATE IN

65

PITCH OUT (+)

66

PITCH OUT (-)

67

GATE OUT

68

GATE / 4 OUT

69

DRUMS OUT

70

RATE IN

71

supersonic ACCELERATOR