

A

B

C



D

A



B

C

D



IC3
MCU STM32L053R6T6



Place VLCD if external LCD power supply is used, not internal step-up converter. Leave open if step up is used? This jumper is connected on the NUCLEO-STM32073 board (SB45)

C_LCD may need to be a larger capacitor if internal step-up converter is used

Place very close to MCU

Connect D_REED_STATE to PA5 TIM2_CH1 or TIM2_ETR (external trigger, if needed)

Title		
Size	Number	Revision
A3		
Date:	9/15/2023	Sheet of
File:	C:\RELJA\13_MCU.SchDoc	Drawn By: