

# NXP MIFARE DESFire Protocol

This document is reverse engineered from various sources and may not be 100% correct. It seems the official protocol is subject to an NDA - if this is not the case, please do let me know! Obviously there is no warranty for any error or mistake I have made.

## Sources

Various testing and experimentation by me (@TheRealRevK), plus blogs and code including :-

- [https://github.com/nfc-tools/libfreefare/blob/master/libfreefare/mifare\\_desfire.c](https://github.com/nfc-tools/libfreefare/blob/master/libfreefare/mifare_desfire.c) (This has actual code that works, and so is a primary source of this manual).
- [https://scancode.ru/upload/iblock/de4/mifare\\_application\\_programming\\_guide\\_for\\_desfire\\_rev.e.pdf](https://scancode.ru/upload/iblock/de4/mifare_application_programming_guide_for_desfire_rev.e.pdf) (This has lots of details but different command codes, useful clues though)
- <https://hack.cert.pl/files/desfire-9f122c71e0057d4f747d2ee295b0f5f6eef8ac32.html> (some useful examples)
- <https://ridrix.wordpress.com/tag/desfire-protocol/> (more useful examples)
- <http://www.ti.com/lit/an/sloa213/sloa213.pdf> (explains more on authentication)
- [https://www.nxp.com/docs/en/data-sheet/MF3ICDQ1\\_MF3ICDHQ1\\_SDS.pdf](https://www.nxp.com/docs/en/data-sheet/MF3ICDQ1_MF3ICDHQ1_SDS.pdf)

## Overview

It is useful to understand what these cards/fobs can do for you!

The card itself has some top level settings, but the idea is that the card can be used with one or more *applications*. This means the same card can be used for travel, access control, currency, all sorts. Each application is independent of the others on the card and is identified by a 3 byte application id (AID). So you select the application you want, and then you can access *files* that are stored relating to that application. In practice this sharing of applications may not happen generally as someone will *own* the card, but it can in theory. With access control I have each site as an application and so one card can work multiple sites independently, which is convenient.

The files within an application are small data storage areas, and there are actually several types of file. The card itself has a total capacity (e.g. 4k), but typically the data stored is small, such as a value or identity. The different types of files include values (e.g. points or currency), or simple binary data, or records of fixed length. One of the clever features is a record file that automatically overwrites the oldest entry when full, ideal for some sort of log of events. There is also a system to ensure integrity (e.g. backup files, and a commit stage after setting up changes).

The files themselves have access permissions controlling read and write and change. The access control is done using *keys*. Each application can have one or more keys. You select the application and then authenticate with a key. Having done this, the access rights you have depend on what key you used. There are also application level access controls and controls on the top level card itself. Each application can have up to 14 keys (a master key and up to 13 others), and the top level card has a master key as well. These keys can use DES, 3DES, or AES encryption. This manual only covers AES. Note, only symmetric authentication exists, i.e. card and reader need same key, and there is no support for public key where one side can check

the other without knowing its secret key. This is a security consideration, as extracting a key from a reader or code means you can make cards that match that key, so consider not storing keys in flash/EEPROM, etc.

The card also allows encryption of the communications, so you cannot snoop data passively when a card is being used.

There are also a number of different types of cards with different storage and features. I am testing using the DESFire EV1 4k cards.

## Communications

I am assuming you have a way to talk to the card. I am using a PN532 which handles the RATS and anti collision and selecting the card and so on, and gives me a 4 or 7 byte card ID. I can then do an **InDataExchange** which allows me to send a command sequence of bytes and get a response sequence of bytes.

Each command starts with a one byte command code, and may have a number of data bytes following depending on the command. The simplest command is one byte only, e.g. **60** gets version details of the card. I will be quoting bytes using hex within this document, so that is **0x60**.

Each response starts with a one byte status code, and may have a number of data bytes following depending on the command and response. The simplest response is one byte, and **00** means success.

There is a way to wrap these commands in an ISO message format, and to perform ISO equivalent versions of commands, which may be better. But this document is trying to cover the native DESFire commands and how they work.

It is important to also realise that there is a whole process to authenticate or encrypt the message and response payloads, explained later. This is important to ensure communications cannot be snooped on.

# Command List

As you can see, many of these command codes are designed to be mnemonic, albeit somewhat convoluted in some cases.

Security related commands		
AA	Authenticate (AES)	Start the authentication process for a key, using AES
1A	Authenticate (ISO)	Start the authentication process for a key, using 3DES or 3K3DES
0A	Authenticate (Legacy)	Start the authentication process for a key, using simple DES
54	Change KeySettings	Change the settings for a key
5C	Set Configuration	Card level configuration
C4	Change Key	Change a key
64	Get Key Version	Returns a key version byte.

Card level commands		
CA	Create Application	Create a new application
DA	Delete Application	Delete an application
6A	Get Applications IDs	Get a list of application IDs
6E	Free Memory	Get free memory details
6D	GetDFNames	Get the data file names
45	Get KeySettings	Get details of a keys settings
5A	Select Application	Select application
FC	FormatPICC	Format the card
60	Get Version	Get version details for card
51	GetCardUID	Get the read ID for the card (can be set so a random ID is used as part of collision detection, rather than the real ID).

Application level commands		
6F	Get FileIDs	Get a list of file IDs
61	Get FileIDs (ISO)	Get a list of ISO file IDs
F5	Get FileSettings	Get file settings for a specific existing file
5F	Change FileSettings	Change file settings for a specific existing file
CD	Create StdDataFile	Creates a file for arbitrary binary data
CB	Create BackupDataFile	Creates a file for arbitrary binary data but with a commit process so changes apply reliably all in one go

### Application level commands

CC	Create ValueFile	Creates a file to hold a 32 bit value
C1	Create LinearRecordFile	Create a file to allow records of fixed size to be added until full
C0	Create CyclicRecordFile	Create a file to allow records of fixed size to be added, clearing the oldest record automatically - ideal for a history or a log
DF	DeleteFile	Delete a file

### Data manipulations commands

BD	Read Data	Read data from standard or backup file
3D	Write Data	Write data to standard or backup file (write to backup only happens when commit is done)
6C	Get Value	Get the value from a value file
0C	Credit	Increase the value in a value file
DC	Debit	Decrease the value in a value file
1C	Limited Credit	Increase the value in a value file without having full permissions to that file, up to a limit
3B	Write Record	Write a record to a linear or cyclic record file
BB	Read Records	Read records from a linear or cyclic record file
EB	Clear RecordFile	Clear a linear or cyclic record file
C7	Commit Transaction	Commit writes to backup, value, or record files
A7	Abort Transaction	Invalid writes to backup, value, or record files

# Status codes

Status codes	
00	Success
0C	No change
0E	Out of EEPROM
1C	Illegal command
1E	Integrity error
40	No such key
6E	Error (ISO?)
7E	Length error
97	Crypto error
9D	Permission denied
9E	Parameter error
A0	Application not found
AE	Application error
AF	Additional frame (more data to follow before final status code)
BE	Boundary error
C1	Card integrity error
CA	Command aborted
CD	Card disabled
CE	Count error
DE	Duplicate error
EE	EEPROM error
F0	File not found
F1	File integrity error

# Detailed commands

Note that data values such as offsets and record counts and access rights, etc, are all sent low byte first.

## AA: Authenticate (AES)

This allows you to authenticate for a specified key number using AES. If the key is not AES you get an AE error back. The key number is the key in the current application. If top level (AID 0) selected or no application selected yet then this is the master key for the card (key 0).

AA	Key ID
----	--------

The response is AF with 16 bytes of data (random).

AF	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

The reader then responds with AF and 32 bytes of data

AF	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX
	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX

The card then responds with a final status code and 16 bytes of data.

00	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

The process establishes that both parties have the same AES key, and creates a session key for further communications.

The way the response is calculated and checked is explained in a later chapter.

## 1A: Authentication (ISO)

This covers 3DES and 3K3DES. This type of encryption is not covered in this manual.

1A	Key ID
----	--------

The response is AF and a number of bytes depending if 3DES or 3K3DES. There is then a reply command (AF) and a final response with status code in a similar way to the AES authentication.

## 0A: Authenticate (Legacy)

This covers DES. This type of encryption is not covered in this manual.

0A	Key ID
----	--------

The response is AF and a number of bytes. There is then a reply command (AF) and a final response with status code in a similar way to the AES authentication.

## 54: Change KeySettings

This allows the settings for the current key to be changed.

Encrypted command	
54	Setting byte

The key settings depend if you are setting the master key for AID 0 (the card level), or for an application.

Bit	Card master key	Application key
0	The master key (i.e. key 0) can be changed	
1	List applications is possible without master key, otherwise card master key is needed.	Get FID list, Get File Settings and Get Key settings are possible, otherwise application master key is needed
2	Create applications is permitted without the master key. Delete needs card master key or app master key. If not set then both need card master key.	Create and Delete file are permitted without master key authentication, otherwise application master key is needed.
3	This setting can be changed. If unset, then that freezes this config.	
4-7	Not used	0-13: Key number required to change any key. 14: Auth with the key to be changed is needed to change. 15: All keys (except master) are frozen (master by bit 0)

## 5C00: Set Configuration (card config)

This sets top level card settings. The CRC is of the everything from command byte to before the CRC.

Encrypted command			
5C	00	Card config byte	CRC

The card config byte contains:-

Bit	Meaning
0	Disable card formatting
1	Enable random UID

## 5C01: Set Configuration (default key)

Not sure what this does, sorry. Perhaps it means the card is logged in with this by default? The CRC is of the everything from command byte to before the CRC.

Encrypted command				
5C	01	Key data, padded with 00 to 24 bytes	Key version	CRC

## 5C02: Set Configuration (Set ATS)

I guess this sets the ATS bytes. The CRC is of the everything from command byte to before the CRC.

Encrypted command				
5C	02	ATS len	ATS data	CRC

## C4: Change Key

This allows a key to be changed. The first CRC is of the everything from command byte to before the CRC.

Encrypted command					
C4	Key no	16 bytes key data (See note below)	Key version byte	CRC	CRC of new key (if changing different key)

If setting the master key for the card level, the key no has bit 7 set to indicate AES.

If changing a different key to the current key, the new key data is the new XOR'd with the old key. A CRC of the new key is included at the end of the message.

This message format is slightly different if not using AES.

## 64: Get Key Version

This gets the version of the key, for AES this is a version byte which can be set when setting the key. This allows you to then know which key to use if there have been different versions of keys in use.

64	Key ID
----	--------

## CA: Create Application

Create a new application. Depending on settings this may be possible without authenticating as the card master key.



CA	AID (3 bytes)	Key setting byte (see command 54)	App setting byte
----	---------------	--------------------------------------	------------------

The key setting byte is described in command 54.

The app setting byte contains:

Bit	Meaning
0-3	Number of keys, 1 to 14
6	Use 3K3DES (if not AES), else DES/3DES (if not AES)
7	Use AES (set bit 6 to 0)

## DA: Delete Application

This allows an application to be deleted. The permission to allow deletion depends on settings, but it always requires authentication.

DA	AID (3 bytes)
----	---------------

## 6A: Get Application IDs

This one byte command gets a list of application IDs, each 3 bytes.

6A	
----	--

## 6E: Free Memory

This gets the free memory, the response is 3 bytes (low byte first).

6E	
----	--

## 6D: GetDFNames

Not sure, sorry.

6D	
----	--

## 45: Get KeySettings

Returns the settings for the specified key - the response is the settings, and number of keys.

45	Key ID
----	--------

## 5A: Select Application

This selects an application.

5A	AID (3 bytes)
----	---------------

## FC: FormatPICC

This formats the card - you need to be authenticated with the card master key for this.

FC	
----	--

## 60: Get Version

This gets the card version details.

60	
----	--

The response is several parts, and uses AF status code on each. Send an AF command to get the next part.

The first part is hardware version

Hardware version	
Vendor ID	04 for NCP
Type	01
Sub Type	01
Major Version	1 byte
Minor Version	1 byte
Storage Size	18 means 4k, 16 means 2k
Protocol Type	05 means ISO 14443-2 and -3

The second part is software version

Software version	
Vendor ID	04 for NCP
Type	01
Sub Type	01
Major Version	1 byte
Minor Version	1 byte

Software version	
Storage Size	18 means 4k, 16 means 2k
Protocol Type	05 means ISO 14443-3 and -4

The last part provides other data

General version	
UID	7 byte UID, starting 04 for NXP
Batch	5 byte batch ID
Week	Week number (BCD coded, one byte)
Year	Year number (BCD coded, one byte)

## 51: GetCardUID

This requests the actual UID for when a card is set to use a random UID.

51	
----	--

The response is encrypted.

## 6F: Get FileIDs

This gets a list of file IDs in the selected application.

6F	
----	--

## 61: Get FileIDs (ISO)

This gets a list of ISO file IDs in the selected application.

61	
----	--

## F5: Get FileSettings

This gets the file settings for a specific file in the application. These are the settings used when creating the file.

F5	File No
----	---------

## 5F: Change FileSettings

This allows file settings to be changed for a specific file in the application.

5F	File No	Comms setting byte	Access rights (2 bytes)
----	---------	--------------------	-------------------------

Communications settings

Bit	Meaning
0	CMAC communications
1	Encrypted communications

Access rights

Bit	Meaning
15-12	Read access
11-8	Write Access
7-4	Read & Write access
3-0	Change Access Rights

Each of the access rights defines what key is needed for the specific access. Key 0-13 are key numbers, but 14 means *free access* and 15 means *no access*.

## CD: Create StdDataFile

Create a standard data file.

CD	File No	Comms setting byte	Access rights (2 bytes)	File size (3 bytes)
----	---------	--------------------	-------------------------	---------------------

## CB: Create BackupDataFile

Create a backup data file.

CB	File No	Comms setting byte	Access rights (2 bytes)	File size (3 bytes)
----	---------	--------------------	-------------------------	---------------------

## CC: Create ValueFile

Create a value data file.

CC	File No	Comms setting byte	Access rights (2 bytes)	Lower limit (4 bytes)	Upper limit (4 bytes)	Initial value (4 bytes)	Limited credit (4 bytes)	Limited credit available (1 byte)
----	---------	--------------------	-------------------------	-----------------------	-----------------------	-------------------------	--------------------------	-----------------------------------

## C1: Create LinearRecordFile

Create a linear record file.

C1	File No	Comms setting byte	Record size (3 bytes)	Number of records (3 bytes)
----	---------	--------------------	-----------------------	-----------------------------

## C0: Create CyclicRecordFile

Create a cyclic record file.

C0	File No	Comms setting byte	Record size (3 bytes)	Number of records (3 bytes)
----	---------	--------------------	-----------------------	-----------------------------

## DF: DeleteFile

Delete a file.

DF	File No
----	---------

## BD: Read Data

Read data from a file.

BD	File No	Offset (3 bytes)	Length (3 bytes)
----	---------	------------------	------------------

## 3D: Write Data

Write data to a file

3D	File No	Offset (3 bytes)	Length (3 bytes)	Data...
----	---------	------------------	------------------	---------

## 6C: Get Value

Get value from a value file.

6C	File No
----	---------

## 0C: Credit

Credit value in a value file. You need to commit the changes.

0C	File No	Amount to credit (4 bytes)
----	---------	----------------------------

## DC: Debit

Debit the value in a file. You need to commit the changes.

DC	File No	Amount to debit (4 bytes)
----	---------	------------------------------

## 1C: Limited Credit

Add limited credit. You need to commit the changes.

1C	File No	Amount to credit (4 bytes)
----	---------	-------------------------------

## 3B: Write Record

Write to a record. The offset/length are within the record. A new record is created with 00 bytes where not written. You need to commit the changes.

3B	File No	Offset (3 bytes)	Length (3 bytes)	Data...
----	---------	---------------------	---------------------	---------

## BB: Read Records

Read records - record 0 is the latest, 1 is the one before that, etc.

BB	File No	Record number (3 bytes)	Number of records (3 bytes)
----	---------	----------------------------	--------------------------------

## EB: Clear RecordFile

Clear all records from a file.

EB	File No
----	---------

## C7: Commit Transaction

Commit updates to value and record files.

C7	
----	--

## A7: Abort Transaction

Abort changes to value and record files.

61	
----	--

# Authentication

As explained in the commands, the authentication using AES involves a 3 way handshake. A request is sent for AES authentication for a specific key, a response (16 bytes) is received from the card. This is processed to make a 32 byte response sent back as a command to the card and then there is a 16 byte response from the card with a status code. If the status code is success (00) then we have successfully authenticated.

The process is as follows.

1. The reader asked for AES authentication for a specific key.
2. The card creates a 16 byte random number (B) and encrypts it with the selected AES key. The result is sent to the reader.
3. The reader receives the 16 bytes, and decrypts it using the AES key to get back the original 16 byte random number (B). This is decrypted with an IV of all 00 bytes.
4. The reader generates its own 16 byte random number (A).
5. The reader rotates B one byte to the left.
6. The reader concatenates A and the rotated B together to make a 32 byte value.
7. The reader encrypts the 32 byte value with the AES key and sends to the card. The IV for encrypting this is the 16 bytes received from the card (i.e. before decryption).
8. The card receives the 32 byte value and decrypts it with the AES key.
9. The card checks the second 16 bytes match the original random number B (rotated one byte left). If this fails the authentication has failed. If it matches, the card knows the reader has the right key.
10. The card rotates the first 16 bytes (A) left by one byte.
11. The card encrypts this rotated A using the AES key and sends it to the reader.
12. The reader receives the 16 bytes and decrypts it. The IV for this is the last 16 bytes the reader sent to the card.
13. The reader checks this matches the original A random number (rotated one byte left). If this fails then the authentication fails. If it matches, the reader knows the card has the AES key too.
14. Finally both reader and card generate a 16 byte session key using the random numbers they now know. This is done by concatenating the first 4 bytes of A, first 4 bytes of B, last 4 bytes of A and last 4 bytes of B.

The session key is then used for further communications.

Example, assuming an AES key of 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

Cmd	
AA	00

Response from card																
AF	B9	69	FD	EE	56	FD	91	FC	9D	E6	F6	F2	13	B8	FD	1E

Decrypt to give B: C0 5D DD 71 4F D7 88 A6 B7 B7 54 F3 C4 D0 66 E8

Decrypt	
Key	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
IV	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Code	B9 69 FD FE 56 FD 91 FC 9D E6 F6 F2 13 B8 FD 1E
Data	C0 5D DD 71 4F D7 88 A6 B7 B7 54 F3 C4 D0 66 E8

Rotate left to give B': 5D DD 71 4F D7 88 A6 B7 B7 54 F3 C4 D0 66 E8 C0

Create random A: F4 4B 26 F5 68 6F 3A 39 1C D3 8E BD 10 77 22 81

Concatenate A and B': F4 4B 26 F5 68 6F 3A 39 1C D3 8E BD 10 77 22 81 5D DD 71 4F D7 88 A6 B7 B7 54 F3 C4 D0 66 E8 C0

Encrypt: 36 AA D7 DF 6E 43 6B A0 8D 18 61 38 30 A7 0D 5A D4 3E 3D 3F 4A 8D 47 54 1E EE 62 3A 93 4E 47 74

Encrypt	
Key	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
IV	B9 69 FD FE 56 FD 91 FC 9D E6 F6 F2 13 B8 FD 1E
Data	F4 4B 26 F5 68 6F 3A 39 1C D3 8E BD 10 77 22 81 5D DD 71 4F D7 88 A6 B7 B7 54 F3 C4 D0 66 E8 C0
Code	36 AA D7 DF 6E 43 6B A0 8D 18 61 38 30 A7 0D 5A D4 3E 3D 3F 4A 8D 47 54 1E EE 62 3A 93 4E 47 74

Further command to card																
AF	36	AA	D7	DF	6E	43	6B	A0	8D	18	61	38	30	A7	0D	5A
	D4	3E	3D	3F	4A	8D	47	54	1E	EE	62	3A	93	4E	47	74

The card responds with: 80 0D B6 80 BC 14 6B D1 21 D6 57 8F 2D 2E 20 59

Response from card																
00	80	0D	B6	80	BC	14	6B	D1	21	D6	57	8F	2D	2E	20	59

Decrypt to get A': 4B 26 F5 68 6F 3A 39 1C D3 8E BD 10 77 22 81 F4



Decrypt																
Key	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
IV	D4	3E	3D	3F	4A	8D	47	54	1E	EE	62	3A	93	4E	47	74
Code	80	0D	B6	80	BC	14	6B	D1	21	D6	57	8F	2D	2E	20	59
Data	4B	26	F5	68	6F	3A	39	1C	D3	8E	BD	10	77	22	81	F4

Match to A rotated one: 4B 26 F5 68 6F 3A 39 1C D3 8E BD 10 77 22 81 F4

Work out session key: F4 4B 26 F5 C0 5D DD 71 10 77 22 81 C4 D0 66 E8

# Encryption

Once authenticated, the command/response process changes slightly. The authentication provides a session key (based on the A and B random codes exchanged), and a session IV (which is all 00 initially).

The plain commands are sent as normal, but they are put through a CMAC process to update the session IV.

The plain responses from the card have an extra 8 bytes added to them. These need to be removed to process the response. The response data is also put through the CMAC process to update the session IV. Once this is done the first 8 bytes of the IV must match the extra 8 bytes added.

Whilst the CMAC of the command is simply processed on the command from the command byte to the end, the processing of the response is more complex. The CMAC is calculated over the payload of the response (i.e after the status byte) and then the status byte appended to the end. If the response is multiple parts then the payload of these parts are concatenated (without the AF status byte) and the final status byte added to the end.

Some commands, such as a setting as new key, are sent encrypted. The command byte is not encrypted, or the sub command for change key settings or key number for changing key. The data after this, including the CRCs, are encrypted. This first involves extending the data to be encrypted to a multiple of 16 bytes by adding 00 bytes (note that there is no 80 involved in padding).

The Get Card UID response is encrypted, starting after the status byte.

File access can require CMAC or encryption on a per file basis.

Authentication stops if there is an error response, or you select another application or change the key you are using.

## CMAC

The CMAC process makes use of the session key and session IV, and updates the session IV. Before starting two sub keys need to be generated.

Subkey1 is generated by:-

1. Encrypting 16 bytes of 00 using the session key and an IV of all 00.
2. Shift the result one bit left.
3. If 1 was shifted off the end (i.e. bit 7 set in first byte before shift) XOR last byte with 87.

For example :-

[illegible]

Making subkey 1	
Encrypted	7D F7 6B 0C 1A B8 99 B3 3E 42 F0 47 B9 1B 54 6F
Shifted	FB EE D6 18 35 71 33 66 7C 85 E0 8F 72 36 A8 DE
XOR 87	Not needed as was 7D does not have top bit set.

Subkey2 is generated by:-

1. Shift subkey 1 left one bit
2. If 1 was shifted off the end (i.e. bit 7 set in first byte before shift) XOR last byte with 87.

Making subkey 2	
Subkey 1	FB EE D6 18 35 71 33 66 7C 85 E0 8F 72 36 A8 DE
Shifted	F7 DD AC 30 6A E2 66 CC F9 0B C1 1E E4 6D 51 BC
XOR 87	F7 DD AC 30 6A E2 66 CC F9 0B C1 1E E4 6D 51 3B

The CMAC process on a block of data involves the following steps.

1. Padding - if zero length, or not a multiple of 16 bytes, add 80 and additional 00 to make a multiple of 16 bytes.
2. If padding was added, XOR the last block (last 16 bytes) with subkey 2
3. If padding was not added, XOR last block (last 16 bytes) with subkey 1
4. Encrypt the data.
5. Update the IV with the result of encryption (the last block). This is the resulting CMAC, the first 8 bytes of which are appended to responses.

For example :- (all assuming these are the first message and so an IV of all 00)

Empty message (i.e. all padding)	
IV	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Padded	80 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
XOR'd	77 DD AC 30 6A E2 66 CC F9 0B C1 1E E4 6D 51 3B
Encrypted	BB 1D 69 29 E9 59 37 28 7F A3 7D 12 9B 75 67 46

16 byte message (i.e. no padding)	
IV	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Message	6B C1 BE E2 2E 40 9F 96 E9 3D 7E 11 73 93 17 2A
XOR'd	90 2F 68 FA 1B 31 AC F0 95 B8 9E 9E 01 A5 BF F4
Encrypted	07 0A 16 B4 6B 4D 41 44 F7 9B DD 9D D0 4A 28 7C

16 byte message (i.e. no padding)

IV	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00															
Message	6B C1 BE E2 2E 40 9F 96 E9 3D 7E 11 73 93 17 2A AE 2D 8A 57 1E 03 AC 9C 9E B7 6F AC 45 AF 8E 51 30 C8 1C 46 A3 5C E4 11															
Padded	6B C1 BE E2 2E 40 9F 96 E9 3D 7E 11 73 93 17 2A AE 2D 8A 57 1E 03 AC 9C 9E B7 6F AC 45 AF 8E 51 30 C8 1C 46 A3 5C E4 11 80 00 00 00 00 00 00															
XOR'd	6B C1 BE E2 2E 40 9F 96 E9 3D 7E 11 73 93 17 2A AE 2D 8A 57 1E 03 AC 9C 9E B7 6F AC 45 AF 8E 51 C7 15 B0 76 C9 BE 82 DD 79 0B C1 1E E4 6D 51 3B															
Encrypted	3A D7 7B B4 0D 7A 36 60 A8 9E CA F3 24 66 EF 97 B1 48 C1 7F 30 9E E6 92 28 7A E5 7C F1 2A DD 49 DF A6 67 47 DE 9A E6 30 30 CA 32 61 14 97 C8 27															
CMAC	DF A6 67 47 DE 9A E6 30 30 CA 32 61 14 97 C8 27															

## CRC

The CRC used is  $x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} + x^{10} + x^8 + x^7 + x^5 + x^4 + x^2 + x + 1$ , with an initial value of all 1s. Note that this is encoded low byte first in messages.

Code example :-

```

unsigned int crc(unsigned int len, unsigned char *data)
{
    unsigned int poly=0xEDB88320;
    unsigned int crc=0xFFFFFFFF;
    int n,b;
    for(n=0;n<len;n++)
    {
        crc^=data[n];
        for(b=0;b<8;b++)
            if(crc&1)
                crc=(crc>>1)^poly;
            else
                crc>>=1;
    }
    return crc;
}

```

For example:-

CRC																
Data	00	10	20	30	40	50	60	70	80	90	A0	B0	B0	A0	90	80
CRC	1979E3BF															
Coded as	BF	E3	79	19												