



NOTES

- *FLANGES NUMBERED FORE-TO-AFT WITH 1ST BEING FWDMOST ETC.
- *ALL FLANGES TO BE CLOCKED WITH OB EDGES PARALLEL TO DECK EDGE RADIUS TANGENT
- *TO BE MOUNTED ON TOE-KICK FLANGES (NOT YET INSTALLED) WITH 3 BOLTS PENETRATING EACH STACKED FLANGE PAIR AND THROUGH DECK; TOE-KICK FLANGES SIZED LARGER TO HOLD ONE ADDITIONAL BOLT & REMAIN FASTENED TO DECK IN CASE OF RAIL & STANCHION REMOVAL