





BASE PLATE CAN BE BOLTED THROUGH FIBERGLASS WITHOUT BUSHINGS AT HIGH DENSITY FOAM CORE LOCATIONS

BASE PLATE SHOWN FOR ENTIRE LENGTH OF TOE-KICK FEATURE. ALTERNATELY CONSIDER ONLY PLACING FLANGES AT HANDRAIL POST/HIGH DENSITY FOAM CORE LOCATIONS FOLLOWING BUILD PRACTICALITY.

PRELIMINARY  
NOT FOR  
CONSTRUCTION

-  HIGH DENSITY FOAM CORE (IN HULL LAMINATE)
-  BASE PLATE - EXACT SIZING TBD (BOLTED TO FIBERGLASS HULLS)
-  POSTS, STANCHIONS, OTHER HARDWARE (WELDED TO BASE PLATE OR SEPARATE FLANGE)
-  JIG FRAME LOCATIONS

