

center this text

2

W Load due to wind pressure See IBC 1609 and Chapter 5 of this

publication

CBC 2019 reference Equation

Equation 16-1	$1.4(D + F)$
Equation 16-2	$1.2(D + F) + I.6(L + H) + 0.5(L \text{ or } S \text{ or } R)$
Equation 16-3	$1.2(D + F) + I.6(Lr \text{ or } S \text{ or } R) + I.6H + (f1L \text{ or } 0.5W)$
Equation 16-4	$1.2(D + F) + 1.0W + f1L + I.6H + 0.5(Lr \text{ or } S \text{ or } R)$
Equation 16-5	$1.2(D + F) + 1.0E + f1L + I.6H + f2S$
Equation 16-6	$0.9D + I.0W + I.6H$
Equation 16-7	$0.9(D + F) + 1.0E + I.6H$

0101-[3] Gravity Loads and Seismic Mass

First floor dimensions Eq-01

variable	value	[value]	description
area1	10700.00 sf	994.06 SM	roof area
area2	100000.00 sf	9290.30 SM	floor area
area3	25.00 sf	2.32 SM	floor area
ht1	9.00 ft	2.74 m	wall height
len1	110.00 ft	33.53 m	interior wall length
len2	155.00 ft	47.24 m	exterior wall length
udl1	12.20 psf	584.14 Pa	description

A line of text extended text - not formatted

variable	value	[value]	description
floordl1	50.00 psf	2394.01 Pa	interior wall length
floordl2	10.00 psf	478.80 Pa	exterior wall length

[from file: c:\gitrivt-solar-canopy-structural-calculations\valsv01test1.csv]

Equation for floor area Eq-02 .. raw:: math

$$wt_{\blacksquare} = area_{\blacksquare} \cdot floordl_{\blacksquare}$$

wt2	floordl1	area2
5000.00 kips	50.00 psf	100000.00 sf
22241108.00 N	2394.01 Pa	9290.30 SM

Equation for wall area Eq-03 .. raw:: math

$$wt_{\blacksquare} = area_{\blacksquare} \cdot floordl_{\blacksquare}$$

■ I■·0.1 =====

$$wt3 \text{ floordl2 area3}$$

25.0 lbs	10.00 psf	25.00 sf
111.2 N	478.80 Pa	2.32 SM

Exterior wall - total area load Eq-04 =====
variable value [value] description ===== len1
410.00 ft 124.97 m interior wall length len2 455.00 ft 138.68 m exterior wall length =====
===== [from file:
c:gitrivt-solar-canopy-structural-calculations\sv01test2.csv]