



# ELECTRONICS TRAINING

Oriol Baldrís and Roger Vendrell



UNIVERSITAT POLITÈCNICA  
DE CATALUNYA  
BARCELONATECH



# WHO WE ARE



We are Oriol (right) and Roger (left), two engineering students from Barcelona who are staying in Cambodia to carry out a collaboration with Trash Is Nice, a plastic recycling station based in Phnom Penh.

Our fields of study are Physics and Artificial Intelligence respectively.

oriol.baldris@estudiantat.upc.edu  
roger.vendrell.colet@estudiantat.upc.edu

# CONTENTS

## 1

## SETUP

- Acces Tinkercad Online
- Register for free
- Create a new project

## 3

## COMPONENTS

- LED
- Sensors

## 2


## BASICS

- Navigation
- Basic tools
- Code and circuit

## 4

## CODING


- Information entry
- Variables



# SETUP

We will work with Autodesk Tinkercad, a free piece of software that lets us simulate arduino boards online, without the need of having a physical one.

Click [here](#) to access.



# Create a circuit



Tinker ▾ Gallery Projects Classrooms Resources ▾



Oriol Baldris Vendrell

Classes

Designs


Tutorials

Challenges

Collections

+ Create collection

What's new



## Your designs

+ Create



3D Design

Circuit

Codeblocks


Create your first 3D design

Recycle bin






# We will work with Arduino Uno board

## What is Arduino?






## A look at our board



# 2


## PROJECT I: BLINK

We will implement a blinking LED,  
creating the circuit and the code.






# 2.0 Breadboard



## 2.1 Circuit



## 2.2 Code

```
void setup()  
{  
  pinMode(13, OUTPUT);  
}
```

The **setup** function helps us define our circuit setup, it will only be executed once at the beginning of the code.


## 2.2 Code

```
void setup()
{
  pinMode(13, OUTPUT);
}

void loop()
{
  // Set PIN 13, the LED ON
  digitalWrite(13, HIGH);
  delay(500); // Wait for 500 millisecond(s)
  // Switch PIN 13, the LED OFF
  digitalWrite(13, LOW);
  delay(500); // Wait for 500 millisecond(s)
}
```

The function **loop** helps us define our main actions in the code, one after the other. It will continuously run in a loop for as long as we run our code.

## 2.3 Exercise: Traffic light




# 3

## TEMPERATURE SENSOR

We will NOW introduce sensors and variables, in this case used to measure temperature.




# 3.1 Sensors



Sensors receive an **input** current and extract an **output** current. This can be either digital or analogue.

It's very important to learn the **characteristics** of each sensor and how to use them.

## 3.2 Temperature sensor




It has three “legs”:

- Voltage in
- Voltage out
- Ground

We have to find an appropriate connection in the board for each!

## 3.3 Circuit design



## 3.4 Coding: variables

We need a place to store our data (in this case, voltage and temperature).

These are variables!

Different types:

- Integer
- Float (decimal values)
- Double (decimal values with extra precision)

And a few more...

```
int baselineTemp = 0;  
int celsius = 0;  
int fahrenheit = 0;
```

## 3.4 Coding: if

We want something to happen **if** a condition is given.

We use the **if** statement to apply this.

```
if (celsius < baselineTemp) {  
    digitalWrite(2, LOW);  
    digitalWrite(3, LOW);  
    digitalWrite(4, LOW);  
}
```

# 4

## PLANT WATERING

A bit more advanced project to  
automatically water your plants.



# 4.1 Concept

We want to water our plants when humidity levels are below desired.

We sense moisture with a sensor.

We use a motor to open our water flow when moisture is too low.



**THAT'S ALL  
FOLKS**

Thank you for your interest.