

LED Panel P10 Fight Timer DMD2 HUB12

User manual (v.: 0.1 - 07/2022)

Features:

- Training (fight) time count and interval count between trainings.
- Countdown time.
- Panel brightness adjustment.
- Allows user to see date and time while counting (makes automatic return).
- Automatically return when idle within the menu tree.
- Audio visual signaling, beep and voice (mp3 files)
- Independent volume control for beep and voice (player has its volume control).
- Playing music on USB flash drive and SD card (player also has FM and Bluetooth).
- Panel operation is independent of mp3 player (shares audio output).
- Displayed temperature range from 2 to 150 °C (Lower temperature needs different hardware).

Display modes: "Timer count" or "Time Date (and temperature)"

Menu access:

- When displaying the Round or Interval count, it allows accessing the counts and notifications settings menu
- For panel brightness adjustment and time adjustment, the panel needs to be displaying the time and temperature.
- To adjust the date, the panel must be displaying the date.

Menu items:

- Round count

Rd:12
34:56

Rd - Round count
12 - Count
34 - Minutes
56 - Seconds

- Interval count

In:12
34:56

In - Interval count
12 - Count
34 - Minutes
56 - Seconds

- Menu reset count

Reset
Cnt?

Resets round and interval counts

- Menu set count

Set
Cnt?

Adjusts the displayed count

- Menu set round

Set
Rd?

Sets the initial value of interval

- Menu set round

Set
Rd?

Sets the initial value of interval

- Menu round notifications

Nt Rd
Off

Select or disable notification type for round (Off/Beep/Voice/Beep+Voice)

- Menu interval notifications

Nt In
Off

Select or disable notification type for interval (Off/Beep/Voice/Beep+Voice)

- Menu beep volume

Volum
B: 5

Select volume for beep

- Menu voice volume

Volum
V: 5

Select volume for voice

- Menu time adjust

b:5
12:34

b - display brightness (min.: 5, max.: 100)

12 - Hours

34 - Minutes

- Menu date adjust

dd/mm
20yy

dd - Day

mm - Month

yy - Year

- HT6P20B remote control (must be 3 buttons)

- **Button 1:** Menu / Next cell

- **Button 2:** Select menu / Change value

- **Button 3:** Exit menu / Switch between Timer or TimeDate

(Note: The order of buttons may vary by remote control manufacturer)