

Locate output caps near connector pin


rusefi.com/s/proteus
github.com/mck1117/proteus
rusEFI


Sheet: /lowside_quad/
 File: lowside_quad.kicad_sch


Title: rusEFI Proteus

Size: A4 Date: 2022-04-09
 KiCad E.D.A. kicad-cli 7.0.7-7.0.7-ubuntu22.04.1

Rev: v0.7
 Id: 3/8







Locate output caps near connector pin

rusefi.com/s/proteus
github.com/mck1117/proteus


rusEFI

Sheet: /lowside_quad1/
 File: lowside_quad.kicad_sch

Title: rusEFI Proteus

Size: A4 Date: 2022-04-09
 KiCad E.D.A. kicad-cli 7.0.7-7.0.7-ubuntu22.04.1

Rev: v0.7
 Id: 6/8



Sheet: /lowside_weak/
File: LS_weak.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. kicad-cli 7.0.7-7.0.7-ubuntu22.04.1

Rev:

Id: 7/8



Sheet: /dinput6/
File: dinput6.kicad_sch

Title:


Size: A4


Date:

KiCad E.D.A. kicad-cli 7.0.7-7.0.7-ubuntu22.04.1


Rev:


Id: 8/8


























A

A

B


B


C


C


D


D











Title		
Size	Number	Revision
A4		
Date:	9.01.2023	Sheet of
File:	C:\Nadezhda\...\power.SchDoc	Drawn By:

