

Mash Cleaning

Ryan Duve


August 18, 2014

Abstract

Only workers highly familiar with the technical aspects of Hifrost are authorized to perform this procedure.

The mash that came from Germany has an unknown amount of air or water vapor in it. We will clean it according the following procedure.


1 Prep




Step 1: Hook up system as shown. Red channels indicate the mash transport path from T3 to the external tank.

- Regenerate LN_2 trap.
- Evacuate T1 with P7.
- Configure the system as shown in Step 1. Purge all lines along the transport path (keeping HVT3 closed!) with P7 to clean the system.
- Leak check the external tank and new connections (e.g., blanked condensor line).
- Close all valves; kill P7; fill trap with LN_2 .


2 Cleaning




Step 2: Open valves in this order: HVT3, HV19, HV20, HV3, HV4, HV5, HV14, HV13, HV12, HV9. Wait until external tank equilibrates with T3.




Step 3: Close HV19, HV20; then open HV17 and turn on P10. Slowly open HV19 and let MT3 drop.




Step 4: When MT3 is around 0 mbar, close HV19, then kill P10. Close HV17. Open HV20 and HV19. Wait until T3 and external tank equilibrate.



Step 5: Close HV19 and HV20. Open HV18 and then start P10. Slowly open HV20; wait until external tank is empty.



Step 6: Repeat Steps 2-5 until MT3 remains constant between passes.



Step 7: Close all valves, then open HV4, HV3, HV20, HV19 and HV1. Warm up trap and record pressure M5 to estimate how much air was removed from mash.