



A output Fuse


DMX 2 motor control box

A output Fuse

Motors A&B Output

Motors Power Input

input fuse



9-12v DC
tip positive

DMX Start Address

DMX 2 motor control box

DMX Input

DMX Thru

indicator
LED