





(KPS) KAWARI POWER SEQUENCER
INTERCONNECTION (SEE PAGE TWO
FOR MORE WIRING DETAILS





KPS INSTALLATION

IMPORTANT SFTUP LOGIC NOTES

The 'switch' header on the Kawari PCB will toggle the chip model between the saved standard (switch open) and the opposite standard (switch closed). Therefore, it is important to wire the right MSM logic output to the KPS J2 PIN 1 which is dependent on your saved standard. See table below.

What's Saved	Swith OPEN	Switch CLOSED	USE PAL LOGIC OUTPUT ON MSM WITH 6567Rx
6567R8 NTSC	6567R8 NTSC	6569R5 PAL-B	
6567R56A NTSC	656756A NTSC	6569R1 PAL-B	USE NTSC LOGIC OUTPUT ON MSM WITH 6569Rx
6569R5 PAL-B	6569R5 PAL-B	6567R8 NTSC	
6569R1 PAL-B	6569R1 PAL-B	6567R56A NTSC	

SOLDER TO CAN
REGULATOR LOCATION
ON EVO MOTHERBOARD

