


Arthritis Typing Aid

ASSEMBLY GUIDE

Required Components

	<p>BOM</p> <ol style="list-style-type: none">1. Aid-top2. Aid-bottom
---	--

Required Tools

- Soldering iron

Required Personal Protective Equipment (PPE)

- Eye protection

Arthritis Typing Aid

ASSEMBLY GUIDE

Assembly Instructions

Step 1

Align the two halves of the device and run a soldering iron around the seam shown with the red dotted line to 'weld' the two halves together. This should be done in a well-ventilated room. Alternatively, the two halves of the device could be glued together.

