


ARMv8M



The diagram shows a light blue rectangular container with a dashed border. Inside this container, the text 'ARMv8M' is centered at the top. Below it, there is a solid black rectangular frame. Inside this frame, the word 'secure' is on the left, and four blue rectangular boxes with black borders are arranged horizontally to its right. These boxes are labeled 'context', 'heap', 'init', and 'macros' from left to right.

secure

context

heap

init

macros