


Combining STLs into a  
single file.

# Download Prusa Slicer

[OUR E-SHOP](#)[OUR 3D PRINTERS](#)[SOFTWARE](#)[PRUSAMENT](#)[3D MODELS](#)[SUPPORT](#)[ABOUT US](#)[PROTECTIVE SHIELDS](#)

Get PrusaSlicer 2.3 **now!**



 **Windows PrusaSlicer Standalone**

This is our new (experimental) installer. Sample objects are an optional download and it features a new auto-updater for PrusaSlicer. Please report any bugs to [info@prusa3d.com](mailto:info@prusa3d.com).


 **Windows Drivers & Apps Package Full Installer**

 **Mac Drivers & Apps Package Full Installer**


 **Linux Drivers & Apps Package Full Installer**

<https://www.prusa3d.com/prusaslicer/>


# Select “File” -> “Import”




# Select the files you want to combine, and click “open”




# Your Screen should look something like this



# Click the “Arrange” Button on the top toolbar



# Select “File” -> “Export” -> “Export plate as STL...”





That's it! If you have any questions feel free to reach out to Ted Sirota at [tsirota\(at\)seas.harvard.edu](mailto:tsirota@seas.harvard.edu)



Happy printing!