

*Group VI aircraft are restricted from using Taxiway Foxtrot east of Ramp 5 North to the west side of Taxiway Charlie.

** Aircraft with wingspan greater than 171' are restricted from using Taxiway Victor.

D LANDING AIRCRAFT CAN EXPECT TO REMAIN ON TOWER FREQUENCY UNTIL SPECIFICALLY INSTRUCTED TO CONTACT GROUND CONTROL. CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES. READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED. FUEL FARMS

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

JANUARY 2020
ANNUAL RATE OF CHANGE
0.1% W

[illegible]

AIRPORT DIAGRAM

ATLANTA, GEORGIA
HARTSFIELD - JACKSON ATLANTA INTL (ATL)