


LOC I-HVD <u>111.9</u>	APP CRS 050°	Rwy Idg 11981 TDZE 815 Apt Elev 815
----------------------------------	------------------------	--


ILS or LOC RWY 5


 For inop ALS, increase S-ILS 5 Cat E visibility to RVR 4000 and S-LOC 5 Cat C/D/E visibility to 1 1/2 SM.		MISSED APPROACH: Climb to 1300 then climbing right turn to 3000 on FWA R-134 to OSBER INT/FWA 22 DME and hold.
---	---	---

ATIS	FORT WAYNE APP CON	FORT WAYNE TOWER	GND CON	CLINC DEL
121.25 360.825	127.2 284.6	119.1 269.325	121.9 348.6	124.75



ELEV	815	D	TDZE	815
------	-----	----------	------	-----



			5 NM		0.1
CATEGORY	A	B	C	D	E
S-ILS 5	1015/18		200 (200-½)	1015/24 200 (200-½)	
S-LOC 5	1300/24	485 (500-½)	1300/50 485 (500-1)		
 CIRCLING	1300-1	485 (500-1)	1420-1¾ 605 (700-1¾)	1520-2¼ 705 (800-2¼)	1520-2½ 705 (800-2½)

