


66 Lock the magnet.

Lock the various  
(XBV, XCV, APH)  
after the adjustment.

62 Lock with the paint  
after the adjustment.

65 Put the silicon grece  
around the Anode.



#### Note

1. Item 63 and 64 must be equipped with item 66 if necessary.

CONFIDENTIAL

T966 (MA-21D5) ASSY SET CRT Drawing