

The harness (CN-UNIT ~ VIDEO-UNIT) must not be caught in SIDE-SHIELD-L and the radiator on the PCB-MAIN.

Close the entrance.

49 Close the entrance.

Put the SUPPORT-T  
in the square hole.

Torque  
6±2kgf.cm

item 37

Seen from B (fixing item 37)

---

Same as another side

## Indication

54 Only two bottom spots

Set Rev No is to print.  
The direction of the letters  
is to be an arrow direction  
and upward.

③1 another side : item 31

30 Insert the five stoppers in the five holes of ASSY-CRT-FRAME. And then, hook the stoppers (BASE: 2, VIDEO: 1).

## Work

53 Clamp tightly with moving item 97 to frontward (Shield side).

### Indication

Check the code number.

Excluding KR, KRK

75 Put SET-LABEL on N.P  
so that it would not be  
on top of the printing of N.P.

### Indication

Check the code number.

69 only for -TR,TRK

Put LABEL-GEA on BACK-  
COVER along the bottom line  
of N.P as the drawing shows.

Stamp a production place.

### Indication

Check the DNHW indication.

Insert Cover-U2  
to ASSY BACK COVER.

Factory	Contents of indication of a stamp.
Matto	EIZO NANAO/Matto,Japan
Nanao	Nanao Electric/Nanao,Japan
Toriya	Nanao Electric/Toriya,Japan

**CONFIDENTIAL**

# T966 (MA-21D5) ASSY SET DISPLAY Drawing