


### 3. USER CONTROL SPECIFICATIONS


#### 3.1 Function & Control

##### A1: Front/Bottom



- (1) ScreenManager (OSD menu)
- (2) D-Sub mini 15 pin input connector
- (3) Power connector
- (4) Power switch

##### A2: Rear



- (5) Auto adjustment button
- (6) Control buttons (Up, Down, Left, Right key)
- (7) Enter button
- (8) Power indicator

#### • Power Indicator (LED)

On	Power saving mode	Advance notice for Off Timer	Off Timer period	Main power switch off
Green	Yellow	Green blinking	Yellow blinking	No light