

<Note>

1. How to put the bottom of the packing case. (OR)

*Automatic packing

Glue the out flap with item 67 and tape by item 92 in the shape of 'I'.


2. Top of the packing case

After packing, tape the top by item 92 in the shape of "I".

Same another side only for manual packing



same as other corners



Fit to the front side.

CONFIDENTIAL

T966 (MA-21D5) ASSY SET PACKING Drawing